Wi-Fi Tubular Motor with Adapter User Manual

01 Product Info

RF Antenna
Wi-Fi antenna
LED
Power line
Motor Head Button(H)

Working temperature
55°C
-10°C

Remote Controller Buttons

LED
Stop
CH-
Fav
Up
CH+
Down

Power Options

CR2460 3V
CR2460
Prg

Models & Parameters (for details about other parameters, see the product nameplate)

JCD	25	S	AE	11	30	W
DC Motor	Tube Diameter: 25 mm	S: Standard / Q: Quiet / P: Performance	With adapter+built-in wireless receiver	Torque: 1.1 N.m	Speed: 30Rpm	Built-in Wi-Fi module

02 Caution!

1. This product is for indoor use only, do not use outdoor or in humid environments.
2. The power supply for this motor is adapter with 12V (Note: Adapter with 8.4V for JCD15SAE).
3. The motor will jog in operation, please do not proceed to the next step until it complete.
4. During operation, the effective interval of the transmitter button operation is 10 seconds. If there is no effective transmitter operation for more than 10 seconds, it will automatically exit the current mode.
5. The motor can be paired with max 10 controllers.
6. Upper&Lower limits cannot be set at the same position, limits saved even power off.
7. The motor runs constantly for at 6 mins max without any other operation.
8. Do not lift the motor by grabbing the wire or antenna.

03 Instructions

Motor head button (H) functions

| Functions	Operation	Jogging time	LED lamp flickers	Note
Control the UP/STOP/DOWN of the shade	Short press	/	/	Can only operate after limits are set
Adding/Removing Controller	Hold for 2s	Jog*1	Flicker*1	Operation needs be done within 10s
Wi-Fi Connecting	Hold for 6s	Jog*2	Flicker*2	Entering Wi-Fi connection mode
Direction Reverse	Hold for 10s	Jog*3	Flicker*3	All settings saved after direction reversed
Reset	Hold for 16s	Jog*4	Flicker*4	All settings deleted

a. Pairing Motor with Controller

Way 1: Before adding a new controller

Power on → Jog x1 → Select channel → Press Prg within 10s → Jog x2 → OK

Way 2: After motor is powered on for more than 10s

H button x2s → Jog x1 → Select channel → Press Prg within 10s → Jog x2 → OK

Way 3: Power on, add controller B via pre-existing controller A

Press Prg on A → Jog x1 → Press Prg on A → Jog x1 → Press Stop on B → Jog x2 → OK

Note: Pairing can not be done under group channel or 0 channel.

b. Direction Reverse

Correct

UP → Shade goes up
Down → Shade goes down

If the limits are not set, and direction goes opposite.

Fav & Stop x2s → Jog x1 → Direction reversed

If limits are set and direction goes opposite.

Prg → Jog x1 → Up x1 → Jog x1 → Down x1 → Jog x1 → OK

Note: Do reverse the direction when it goes opposite.

c. Upper&Lower Limits Setting

Up or Down → Fix upper point → Up & Fav x2s → Jog x2 → Upper limit set

Up or Down → Fix lower point → Down & Fav x2s → Jog x2 → Lower limit set

Note: Upper&Lower limits cannot be set at the same point.
Before limits set, the motor will run in one-touch mode by pressing Up or Down, hold Up or Down for 2s, motor runs in constant-touch mode.
Once limits set, press Up or Down, motor runs in constant-touch mode.

d. One-touch/Constant-touch Mode

Constant-touch ------>One-touch

Prg → Jog x1 → Stop → Jog x1 → Stop → Jog x1 → OK

Same operation can toggle from one-touch to constant-touch mode.
Note: When motor in one-touch mode, hold Up or Down for more than 2s, it will run in constant-touch mode.

e. Setting and Cancelling Favorite Position

Setting

Up or Down → Fix Fav. position → Fav & Stop x2s → Jog x2 → Fav. position set

Cancelling

Shade is at Fav. position → Fav & Stop x2s → Jog x1 → Fav. position Cancel

f. Hot key to the Fav. Position

Fav → fast get to the Fav. point

Note: The Fav.position setting only can be done after upper&lower limits set.

g. Adjusting Upper & Lower Limits

Adjust Upper limit

Up & Fav x6s → Jog x1 → Up or Down → Fix new upper limit → Up & Fav x2s → Jog x2 → OK

Adjust Lower limit

Down & Fav x6s → Jog x1 → Up or Down → Fix new lower limit → Down & Fav x2s → Jog x2 → OK

Note: The operation should be done within 4mins.

h. Adjusting Motor Speed

Prg → Jog x1 → Stop → Jog x1 → Up → Jog x1 / Down → Jog x1

→ Speed increase
→ Speed decrease

Note: If motor doesn't jog, the max/min speed has already been reached. There are 3 speeds adjustable.

i. Removing Controllers

Remove a single controller

H button x2s → Jog x1 → Prg → Jog x1 → OK

Remove controller B via pre-existing controller A

Prg on existing A → Jog x1 → Prg on existing A → Jog x1 → Stop on B (to remove) → Jog x1

→ Controller B removed

Remove all controllers:

| Prg | Jog x1 | Prg | Jog x1 | Down | Jog x1 |

➜ All controllers removed

Note: All the settings are saved even controllers removed(limits set are saved)
Controller A/B are already paired to motor

j.Canceling Limits

| Prg | Jog x1 | Stop | Jog x1 | Prg | Jog x1 |

➜ Limits cancell

Note: Motor running without limits is forbidden when shade already installed.
Limits should be set immediately to protect the shade.

04 Connecting to Wi-Fi network

*Connection requirement
The smart phone needs to connect to Wi-Fi network and turn on the Bluetooth function first.

① Download APP

a.Search for "Smart Life" in the app store or scan the QR code


b.Complete account registration and login to the app

c. Operate the motor to enter Wi-Fi network connection mode：

Way 1

| Hx6s | Jog x2 | (Orange)LED flickerx2 | (Blue)LED flicker |

➜ Wi-Fi connecting

Way 2:

| Prg | Jog x1 | Down | Jog x1 | Up | Jog x1 |

➜ Wi-Fi connecting

(Blue)LED flicker

d. Click "+" in the upper right corner of the APP, then click "Auto Scan", the APP will automatically search for tubular motor

e. Click "Next" when you find the device, enter the Wi-Fi account password and click "Confirm" to connect.

f. After adding device successfully, tap " ✎ " after the device name to modify the device name.

g.After the motor device is added successfully, the LED on motor head will be on for 10s and then go off.

LED

---

h.Now the motor can be controlled by App from anywhere, anytime

05 Troubleshooting

Fault	Cause	Solution
Motor does not work	1.Controller not paired 2.Motor inactive	1.Add controller 2.Hold H button for 2s to activate motor
Motor stops suddenly	1.Upper & Lower limit set incorrectly 2.Shade exceed rated load	1.Re-set Upper & Lower limits 2.Adjust load
Motor just goes in one direction	Wrong limits set	Cancel original limits, set new limits